

# RAPTOR®

## TOUGH PROTECTIVE COATINGS



Products you will need

### HOW TO SPRAY A BONNET AND ADD A STENCIL



1

#### APPLY RAPTOR

Spray the vehicle in the colour and texture of your choice.



2

#### LAY THE STENCIL

Once fresh RAPTOR has cured, lay the stencil over the area and press down firmly.



3

#### PAINT THE STENCIL

Mask the rest of the car and paint your stencil.



4

#### ADD THINNER IF NEEDED

To achieve a fine / flat texture, use a 1.6mm tip with RAPTOR thinned at 20% with our SYSTEM 20 fast thinner.



5

#### ALLOW TO DRY

Allow RAPTOR to dry.



6

#### DEMASK

Demask after RAPTOR has cured.



### NOTES:

IF USING STENCIL OVER AGED RAPTOR, DEGREASE THE AREA BEFORE LAYING THE STENCIL. THEN APPLY 1-2 COATS OF RAPTOR ADHESION PROMOTER BEFORE APPLICATION OF RAPTOR.

[WWW.RAPTORCOATINGS.COM](http://WWW.RAPTORCOATINGS.COM)

U-POL Ltd, 4th Floor, The Grange, 100 High Street, London N14 6BN.

T: +44 (0)20 8492 5900 E: [uk.sales@u-pol.com](mailto:uk.sales@u-pol.com)

U-POL TECHNICAL SUPPORT:

**+44 (0) 1933 230310**